

Dancefloor

Note


- Ensure ground under panels is firm and even. If assembling on grass or dirt place a plastic sheet or tarpaulin under the panels.
- Do not place panels in a position where they may be affected by water.
- Do not use oil, grease or sprays, such as WD40, to lubricate the locking mechanisms as this will attract dirt possibly jamming the mechanism.
- Do not use strong cleaning agents, chemicals or abrasive cleaners. If mopping is necessary use warm water and mild detergent.
- Do not use floor when wet as the panels can become slippery and may cause serious injury.

Storage / Transport

- Always stack panels face to face and back to back to prevent damage to panel surface. When transporting panels lay flat on a firm base.

Assembly

1. Position the first panel in the top left corner of the floor location ensuring the 'tongued' edges are toward the outer edges of the floor.
2. Assemble the remainder of the floor in the diagonal sequence as shown in the diagram.
3. To ensure that the floor doesn't pull apart ensure all panels are tightly locked together as you lay them down (see below).



Locking / Unlocking Panels

Locking

- With panel edges placed tightly together, insert a 3/16" Allen key completely into the lock openings on each panel and turn 180° clockwise (until the key no longer turns easily) ensuring the panels are pulled together tight.

Un-locking

- Insert a 3/16" Allen key completely into the lock openings on each panel and turn 180° anticlockwise then pull the panels apart. Do not attempt to move or pull apart panels until they have been unlocked.

Edge Trim

- Attach edge trim, if supplied, to all sides of the floor. Push the grooved trim strips onto the tongued edges and the tongued trim strips onto the grooved edges. Lock and unlock trims as per instructions above.

Cleaning

- After use give the floor area a sweep or vacuum to remove excess dirt and grime to prevent damage when stacked ready for storage / transport.
- If spilt drinks / food or water / mud is present on the floor give the floor area a clean using a damp mop to prevent damage when stacked ready for storage / transport.
- Do not use water from a hose or bucket to wash down the floor panels.

Enjoy the beat of the music and dance as if nobody is watching.